


**NOTE:** THE SERIAL NUMBER PROVIDES THE FOOTREST WIDTH. IF THE SERIAL NUMBER IS NOT AVAILABLE, USE THE INSET FORMULA (ABOVE) TO CALCULATE.

**PLATFORM FOOTREST DESCRIPTION KEY**



**INSET FORMULA**

0" INSET: (SEAT WIDTH) - 1"=(FOOTREST WIDTH)  
 1" INSET: (SEAT WIDTH) -3"=(FOOTREST WIDTH)  
 2" INSET: (SEAT WIDTH) -5"=(FOOTREST WIDTH)

Description	Remarks
Part	
Part	